



Savi 745, Convertible + deluxe charging cradle kit, W745



Savi 740, Convertible, W740



Savi 730, Over-the-ear, W730



Savi 720, Binaural, W720



Savi 710, Monaural, W710

In the Box

SAVI 745

Headset and Battery	Base
Over-the-head Headband	AC Power Supply
Behind-the-head Neckband	Telephone Interface Cable
Headset Fit Kit	USB Cable
Deluxe Charging Cradle	Quick Start Guide
Spare Battery	

SAVI 740

Headset and Battery	Base
Over-the-head Headband	AC Power Supply
Behind-the-head Neckband	Telephone Interface Cable
Headset Fit Kit	USB Cable
Charging Cradle	Quick Start Guide

SAVI 730

Headset and Eartips	AC Power Supply	Quick Start Guide
Charging Cradle	Telephone Interface Cable	
Base	USB Cable	

SAVI 720

Headset	AC Power Supply	Quick Start Guide
Charging Cradle	Telephone Interface Cable	
Base	USB Cable	

SAVI 710

Headset	AC Power Supply	Quick Start Guide
Charging Cradle	Telephone Interface Cable	
Base	USB Cable	

Spares and Replacement Parts

PART NO.

71782-01	Ear Cushions, Leatherette (2) (W710/W720)
72742-02	Headband Support (W710/W720)
72913-01	Eartips: 5, 3 with Gel Tips (W730)
81423-01	AC Power Supply, Straight Plug
82905-21	Over-the-ear Headset and Charge Cradle (W730)
83322-11	Over-the-head Headset and Charge Cradle (W720)
83323-11	Over-the-head Headset and Charge Cradle (W710)
83356-01	WH500 Convertible Headset and Charge Cradle (W740)
83769-11	Charging Cradle* (W730)
83776-11	Over-the-head Charging Cradle (W710/W720)
84598-01	Savi Spare Battery (W740/W745)
84599-01	Standard Charging Cradle (W740)

*Includes cradles for old and new W730 headsets (non-magnetic/SMIF and magnetic)



71782-01



72742-02




72913-01




81423-01




82905-21



83322-11



83323-11



83356-01



83769-11



83776-11



84598-01




84599-01



84600-01



84604-01



84605-01



84606-01



87229-01



202599-03



71781-01




80287-01



84601-01



84602-01



84603-01



84609-01



86005-01



204755-01



37818-11




37820-11



38350-12



38439-11



38633-11



38734-11



60961-35



78887-01



202578-01

Spares and Replacement Parts (continued)

PART NO.

- 84600-01 Deluxe Charging Cradle (W745)
- 84604-01 Savi Fit Kit, Earloops/Earbuds/Foam Cushions (W740/W745)
- 84605-01 Over-the-head Headband (W740/W745)
- 84606-01 Behind-the-head Neckband (W740/W745)
- 86009-01 Telephone Interface Cable, *pictured on page 4*
- 86658-01 USB Cable, *pictured on page 45*
- 87229-01 Leatherette Ear Cushions, 2 Units (W740/W745)
- 202599-03 Headset Battery (w/ Removal Tool) (W710/W720)

Accessories

- 71781-01 Ear Cushions, Foam (2) (W710/W720)
- 80287-01 On-Line Indicator, Straight Plug
- 82905-21 Over-the-ear Headset and Charge Cradle (W730), *pictured on page 4*
- 83322-11 Over-the-head Headset and Charge Cradle (W720), *pictured on page 4*
- 83323-11 Over-the-head Headset and Charge Cradle (W710), *pictured on page 4*
- 83356-01 WH500 Convertible Headset and Charge Cradle (W740), *pictured on page 4*
- 84601-01 Deluxe Charging Cradle Kit (W740) (Deluxe Charging Cradle + Spare Battery)
- 84602-01 USB Deluxe Charger (W745)
- 84603-01 USB Deluxe Charging Kit (W740) (Deluxe Charger + Spare Battery)
- 84609-01 Charge Base, 5 Units, 3 Pins (with AC Power Supply)
- 86005-01 Charge Base, 1 Unit, 3 Pins (with AC Power Supply)
- 87527-01 Foam Ear Loop Covers, 20 Units (W740/W745), *pictured on page 3*
- 88940-01 Spare Eartips, 25 units, small (W740/W745), *pictured on page 3*
- 88941-01 Spare Eartips, 25 units, medium (W740/W745), *pictured on page 3*
- 204755-01 Savi Spare Battery w/ on/off switch (W740/W745)

Cables and Connectors for Remote Desk Phone Call Control

- 37818-11 APS-11, Electronic Hook Switch, Siemens®/Funwerk®/Auerswald®/Agfeo®/Aastra®/DeTeWe®
- 37820-11 APT-31, Electronic Hook Switch, Avaya® Gmbh (Tenovis)
- 38350-12 APC-42, Electronic Hook Switch, Cisco
- 38439-11 APP-51, Electronic Hook Switch, Polycom®
- 38633-11 APV-66, Electronic Hook Switch, Avaya (EU24)
- 38734-11 APV-63, Electronic Hook Switch, Avaya
- 38908-11 APA-23, Electronic Hook Switch, Alcatel®, *pictured on page 7*
- 60961-35 HL10 Handset Lifter, Straight Plug
- 78887-01 RD-1 Electronic Hook Switch, Shoretel®/Toshiba®/Adtran®/Allworx®
- 85638-01 EHS Extension Cable, Cisco, *not pictured*
- 87317-01 APC-45, Electronic Hook Switch, *pictured on page 7*
- 87327-01 APD-80, Electronic Hook Switch, *pictured on page 7*
- 89280-11 APN-91, Electronic Hook Switch, NEC®, *pictured on page 9*
- 201081-01 APC-82, Electronic Hook Switch, Cisco, *pictured on page 9*
- 202578-01 APU-72, Electronic Hook Switch, Avaya (Nortel®)/Cisco